

Meridian IVR

Installation Guide

Publication number: 555-9001-210
Product release: Meridian IVR 2.0/I
Document release: Standard 1.0
Date: February 1996

© 1996 Northern Telecom
All rights reserved

Printed in the United States of America

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant.

Nortel, Meridian IVR, Meridian Mail, ACCESS, and Meridian 1 are trademarks of Northern Telecom. DEC and VT420 are trademarks of Digital Equipment Corporation. HP, LaserJet, and ThinkJet are trademarks of Hewlett-Packard Company. UNIX is a registered trademark of AT&T.

Publication history

February 1996

This document is the first standard issue for Meridian IVR release 2.0/I.

Contents

About this guide xv

Who should use this manual	xv
How to use this manual	xv
Additional Meridian IVR guides	xvii

Chapter 1: Installation overview 1-1

Before installing the IVR system	1-1
Upgrades, conversions, and expansion	1-2
Configuring your system	1-3
Choosing your language	1-3
Warranties	1-4

Chapter 2: Installation 2-1

The installation process	2-1
Tools and equipment	2-1
Installation sequence	2-4
Selecting a site	2-5
Unpacking the Application Processor	2-5
Setting up the Application Processor	2-5
Physical security	2-6
Visual inspection	2-7
Meridian IVR physical configuration	2-8
Cable connections	2-12
Meridian IVR cables	2-12
ACCESS link cabling	2-12
Connecting peripheral devices	2-17
Optional hardware devices	2-19
Audio line interface	2-19
DEC dot matrix printer	2-21
Installing the key lock security device	2-22

Connecting the power cords	2-22
Turning on your system	2-23
Power-on self-test	2-23
Power switch operation	2-25
Power up and sanity check	2-25
Setting time zones and daylight savings	2-27
Checking the key lock security device	2-27
Printing the HP LaserJet 4M Plus self-test page	2-28
Configuring printer drivers	2-29
Connecting Meridian IVR to a host system	2-37
Configuring the US Robotics modem	2-38
Adding networking options	2-39
Configuring the Ethernet adapter for LAN	2-39
Configuring the Madge Token-Ring adapter	2-45
Configuring the Arnet SYNC/570 adapter	2-56

Chapter 3: Configuring Meridian IVR for testing 3-1

Overview	3-1
Shared resource configuration	3-3
Configuring the Meridian 1 switch	3-5
Configuring Meridian Mail	3-7
Configuring the ACCESS links	3-8
Setting the link speed on the Meridian IVR AP	3-16
Providing SEER and administrative printing	3-16
Configuring Voice Service DN's and mailboxes	3-19
Installing voice prompts from tape	3-20
Configuring Meridian IVR voice channels	3-25
Accessing the System Configuration window	3-26
Setting the number of prompts on the system	3-29
Defining the node type	3-31
Defining node characteristics	3-31
Configuring channels	3-33
Saving changes	3-37
Synchronizing date and time	3-38
Restarting with the new configuration	3-38

Chapter 4: Running the test application 4-1

How it works	4-1
Access Meridian IVR	4-2
Starting Meridian IVR	4-4
Loading an application	4-8

Assigning channels	4-13
Starting the application	4-15
Placing a call to the test application.	4-16
Stopping the test application	4-16
Unloading the application.	4-17
Exiting Application Management	4-19
Logging Out of Meridian IVR	4-20

Chapter 5: Configuring Meridian IVR for customer applications **5-1**

Overview	5-1
Shared IVR channel configuration (single application)	5-1
Shared IVR channel configuration (multiple applications)	5-4
Dedicated IVR channel configuration.	5-8
Hybrid Meridian IVR channel configuration	5-11
Shared configuration when available voice channels exceed IVR logical channels.	5-12
Configuration notes for Meridian Mail Release 9 systems.	5-15
Single port type	5-16
Mixed port types	5-17
Meridian IVR configuration notes.	5-19
Configuring an isolated test environment	5-21
Meridian IVR interaction with Customer Controlled Routing . .	5-22

Appendix A: Meridian IVR components **A-1**

Hardware platforms	A-5
------------------------------	-----

Appendix B: Making changes **B-1**

Prerequisites	B-1
Upgrading the SCO operating system	B-2
Upgrading from a Run-time to Development system	B-2
Conversions and expansion.	B-3
Conversion.	B-3
Expansion	B-3
Software reinstallation procedures.	B-3
Physical inventory	B-4
System backup	B-4
Reinstalling the operating system	B-4
Entering single user mode.	B-5
Reinstalling the IVR application software	B-5

Installing a second hard drive	B-8
The System Configuration Utility	B-10
Reserializing the Meridian IVR system	B-10
Appendix C: Cable pin out data	C-1
Modem cable	C-1
Appendix D: Customized screen text	D-1
Appendix E: Meridian Mail platform compatibility	E-1
Appendix F: ACCESS tool kit diagnostics	F-1
ACCESS tool kit diagnostics	F-2
ACCESS components	F-3
Meridian Mail tool kits	F-3
Application processor components	F-4
Commands	F-4
MMVERIFY	F-5
APVERIFY	F-9
OMRESET	F-10
Diagnosing ACCESS configuration problems	F-10
Enabling ACCESS	F-10
ACCESS link cable	F-10
Viewing hardware database settings	F-11
Glossary	Glossary-1
List of figures	
Figure 2-1 Connecting the ESD wrist strap	2-2
Figure 2-2 Using the conductive foam pad	2-2
Figure 2-3 Required tools	2-3
Figure 2-4 Setting up the Application Processor	2-6
Figure 2-5 Cabinet bay doors	2-7
Figure 2-6 Sample Meridian IVR system configuration	2-8
Figure 2-7 Meridian IVR system configuration (peripherals)	2-9
Figure 2-8 Meridian IVR configurations	2-10
Figure 2-9 ACCESS link cabling	2-14
Figure 2-10 Modular Option EC cabling overview for RS-232	

	multiport cables	2-15
Figure 2-11	Modular Option EC unshadowed system—ports for peripheral devices	2-16
Figure 2-12	Modem cable connections	2-19
Figure 2-13	Connecting the Audio Line Interface	2-21
Figure 2-14	Meridian IVR settings for self-test page for the HP LaserJet 4M Plus printer	2-29
Figure 2-15	System administration window	2-30
Figure 2-16	Configure printer window	2-31
Figure 2-17	Adding a printer to the system	2-32
Figure 2-18	Printer configuration window	2-33
Figure 2-19	Adding printer information	2-34
Figure 2-20	Printer pop-up window	2-35
Figure 2-21	Adding the printer values	2-36
Figure 2-22	Connecting Meridian IVR to the host	2-37
Figure 2-23	Modem configuration settings	2-38
Figure 3-1	Meridian IVR/Meridian Mail configuration for a shared model (single application)	3-3
Figure 3-2	Basic Meridian 1 ACD configuration	3-5
Figure 3-3	Determine the DN of the main ACD queue	3-6
Figure 3-4	Node Configuration window for a Meridian Mail Card Option system	3-9
Figure 3-5	Modify Node window for a Meridian Mail Card Option system	3-13
Figure 3-6	Data Port Configuration window for a Meridian Mail Card Option system	3-14
Figure 3-7	Modify Data Port window (ACCESS/MMlink)	3-15
Figure 3-8	Node configuration window for a Meridian Mail Card Option system	3-17
Figure 3-9	Voice Services-DN Table	3-19
Figure 3-10	Meridian IVR login window	3-26
Figure 3-11	Meridian IVR MMI desktop for vad or root accounts	3-27
Figure 3-12	Meridian IVR main menu	3-28
Figure 3-13	Accessing the System Configuration window	3-28
Figure 3-14	System Configuration window	3-29
Figure 3-15	Node type configuration window	3-31
Figure 3-16	Channel configuration window	3-34
Figure 3-17	Save Changes pop-up window	3-37
Figure 4-2	Meridian IVR main menu	4-4
Figure 4-3	System monitor	4-5

Figure 4-4	System monitor node status.....	4-6
Figure 4-5	Port Status pop-up window	4-7
Figure 4-6	Accessing Application Management window	4-8
Figure 4-7	Application Management menu.....	4-9
Figure 4-8	Application Management window.....	4-10
Figure 4-9	Load or unload application pop-up menu	4-11
Figure 4-10	Select an application to load pop-up menu	4-12
Figure 4-11	Loaded application	4-13
Figure 4-12	Application assigned to channels.....	4-14
Figure 4-13	Start or Stop Application pop-up menu	4-15
Figure 4-14	Start or Stop Application menu	4-17
Figure 4-15	Load or unload application pop-up menu	4-18
Figure 4-16	Application Management menu.....	4-19
Figure 4-17	Meridian IVR menu—left mouse button	4-20
Figure 5-1	Meridian Mail/Meridian IVR configuration for the single-application shared model.....	5-3
Figure 5-2	Meridian 1/SL-1 ACD configuration for the single-application shared model.....	5-3
Figure 5-3	Meridian Mail/Meridian IVR configuration for the multiple applications shared model	5-6
Figure 5-4	Typical Meridian 1/SL-1 ACD configuration for the multiple applications shared model	5-6
Figure 5-5	Sample application selector program for Meridian IVR	5-7
Figure 5-6	Meridian Mail/Meridian IVR configuration for the dedicated model	5-10
Figure 5-7	Typical Meridian 1/SL-1 ACD configuration for the dedicated model	5-10
Figure 5-8	Meridian Mail/Meridian IVR configuration for the hybrid model	5-11
Figure 5-9	Meridian 1/SL-1 ACD configuration for the hybrid model	5-12
Figure 5-10	8 Dedicated Voice Mail and 12 Shared Channels.	5-13
Figure 5-11	Configuring 20 Meridian Mail agents with 12 Meridian IVR logical channels.....	5-15
Figure F-1	Meridian ACCESS diagnostics screen	F-3
Figure F-2	MMVERIFY output screen example	F-7
Figure F-3	MMVERIFY output screen example	F-8
Figure F-4	APVERIFY output screen.....	F-9
Figure F-5	APVERIFY output screen (link not operational)	F-10

List of tables

Table 2-1	Token-Ring Interrupt/Memory address and I/O port address list	2-45
Table 3-1	Overlay 23-ACD queue parameters (for shared channels).....	3-7
Table 3-2	Recommended data port uses for a Meridian Mail Options, Modular Option system	3-10
Table 3-3	Recommended data port uses for a Meridian Mail Modular Option EC system	3-11
Table 5-1	Mixed port type configuration, ALL channels in service	5-17
Table 5-2	Mixed port type configuration, basic ports out of service	5-18
Table A-1	Meridian IVR system component list.....	A-1
Table A-2	Meridian IVR and Meridian Mail platforms	A-5
Table C-1	Application Processor (Port B)-to-modem cable	C-1
Table E-1	Compatibility with Meridian Mail.....	E-1

List of procedures

Procedure 2-1	Connecting the ACCESS link to the Meridian Mail Options platform	2-13
Procedure 2-2	Connecting the ACCESS link to the Modular Option EC platform	2-13
Procedure 2-3	Connecting the monitor and keyboard to the Application Processor.....	2-17
Procedure 2-4	Connecting the printer to the Application Processor	2-17
Procedure 2-5	Connecting the UPS	2-18
Procedure 2-6	Connecting the external modem (optional)...	2-18
Procedure 2-7	Using the optional Audio Line Interface	2-20
Procedure 2-8	Connecting the key lock security device.....	2-22
Procedure 2-9	Powering up Meridian IVR.....	2-25
Procedure 2-10	Checking the key lock security device	2-27
Procedure 2-11	Invoking the HP Laserjet 4M Plus self-test...	2-28
Procedure 2-12	Configuring the printer drivers	2-29
Procedure 2-13	Connecting Meridian IVR to a host computer	2-37
Procedure 2-14	Configuring the US Robotics modem	2-38
Procedure 2-15	Configuring the Ethernet adapter	2-39
Procedure 2-16	Configuring the Token-Ring adapter from DOS	

		2-45
Procedure 2-17	Configuring the Token-Ring adapter for LAN connectivity from UNIX	2-46
Procedure 2-18	Configuring the Token-Ring adapter for 3270/5250 host connectivity from UNIX	2-51
Procedure 2-19	Configuring the Arnet host adapter.....	2-56
Procedure 3-1	Configuring a new Meridian Mail/Meridian IVR installation.....	3-6
Procedure 3-2	Configuring a data port on Meridian Mail for ACCESS.....	3-8
Procedure 3-3	Configuring a data port on Meridian Mail for dedicated printer use.....	3-17
Procedure 3-4	Configuring a Voice Service DN and a mailbox	3-19
Procedure 3-5	Adding voice prompts from tape	3-20
Procedure 3-6	Backing up the voice prompts	3-20
Procedure 3-7	Copying voice prompts to Meridian Mail.....	3-21
Procedure 3-8	Copying voice prompts from Meridian Mail to tape.....	3-23
Procedure 3-9	Accessing the System Configuration window	3-26
Procedure 3-10	Setting the number of prompts	3-29
Procedure 3-11	Defining the node type.....	3-31
Procedure 3-12	Define the node characteristics	3-31
Procedure 3-13	Defining the operational characteristics of the voice channel.....	3-33
Procedure 3-14	Saving your changes	3-37
Procedure 3-15	Synchronizing the date and time	3-38
Procedure 3-16	Stop and restart Meridian IVR	3-39
Procedure 4-1	Logging into the Meridian IVR system.....	4-3
Procedure 4-2	Starting Meridian IVR	4-4
Procedure 4-3	Starting the system monitor.....	4-4
Procedure 4-4	Loading an application.....	4-10
Procedure 4-5	Assigning channels to an application	4-13
Procedure 4-6	Starting the application	4-15
Procedure 4-7	Testing the application.....	4-16
Procedure 4-8	Stopping the application	4-16
Procedure 4-9	Unloading the application	4-17
Procedure 4-10	Exit application management	4-19
Procedure 4-11	Logging out of Meridian IVR.....	4-20
Procedure 5-1	Configuring the PBX to provide IVR service.	5-23

Procedure B-1	Installing the MIT tape and diskettes.....	B-2
Procedure B-2	Installing the IVR application tape	B-2
Procedure B-3	Rebooting the system.....	B-5
Procedure B-4	Reinstalling the IVR software	B-6
Procedure B-5	Installing a second hard drive.....	B-8
Procedure B-6	Invoking the reserialization script	B-11
Procedure F-1	Running Meridian ACCESS diagnostics.....	F-4